



7035 SERIES

Ultra flat
Self-Priming
Zéro COV

Acrylic latex

TECHNICAL DATA SHEET

DESCRIPTION

Our **Proline Eco 7035** is a Zero VOC acrylic latex ceiling flat finish paint for indoor use. **Proline Eco 7035** does not contain any volatile organic compounds that can contribute to air pollution. It can be applied directly onto porous surfaces without requiring a primer. It is easy to apply, without spattering and dries quickly. It was developed to answer the needs of professional painters. The **Proline Eco 7035** can be used for commercial, industrial and residential projects.

USE	LIMITATIONS
This paint is applicable on interior surfaces. Proline Eco 7035 must be applied to surfaces that have been well prepared. It is self-priming and can be applied directly onto porous surfaces that haven't been primed. It is recommended for ceilings. Its ultra-flat finish provides an attenuated gloss on required surfaces and is ideal for open rooms and/or rooms with multiple windows.	Avoid application in all temperatures under 10°C Not for exterior use Do not use on flooring Do not apply on glossy surfaces.

CARACTERISTICS	TECHNICAL INFORMATION		
<ul style="list-style-type: none"> • Proline Eco 7035 is ideal for LEED projects or any other projects requiring Zero VOC paints. • It does not require the use of a primer sealer on new drywall. • It will conceal surface imperfections with its ultra-flat finish. 	DRYING TIME	Recoat: 4 hours	To touch: 30 minutes
	At 25° Celsius. Relative humidity at 50%.		
	SURFACE COVERAGE (for 3.78 L)	33 - 42m ² (350 - 4500 ft ²) May vary depending on the surface porosity	
	Recommended film thickness	Wet : 3.75 - 4.65 mils Dry : 1.55 - 1.90 mils	
	Cleaning	Lukewarm soapy water	
	Resin	Acrylic latex	
	Thinner	Water	
	Inflammability	N/A	
	Flash point	N/A	
	% of solids by weight	59%	
	% of solids by volume	41%	
	VOC	Zero VOC	
	GLOSS	60° 1.5 – 2% 85° 1.0 – 1.5%	
	Ultra flat	The value is measured based on the white. The value may vary according to the chosen colour.	

TINTING BASES

		946 ml	3,78 L	18,9 L	
7035-0	White		X	X	
7035-9	Natural Base		X	X	max. of 2 oz of colorant/3,78 L

* Once tinted, **Proline Eco 7035** will no longer be considered a Zero VOC paint.

SURFACE PREPARATION	RECOMMENDED PRIMER
<p>The surface must be dry and clean, without dust, oil, grease, rust and soap. On painted surfaces, it is recommended to clean with a degreaser (T.S.P.) in order to eliminate any contaminant that may harm the adhesion or the curing of the product. Thoroughly rinse the entire surface. The surfaces must be well sanded and dusted.</p> <p>Presence of mold: Clean the affected area with a mixture of 1 part bleach to 3 parts water. Thoroughly rinse the entire surface.</p> <p>Flaking or peeling paint: Using a scraper, remove the weakened and/or loose paint, then sand the edges of the surface to make it smooth.</p> <p>A repair compound should be used to fill holes and uneven surfaces. Sand with a grit #100 sandpaper.</p> <p>New drywall : To avoid creating an undesirable texture on the drywall, the joint compound must not be sanded excessively.</p> <p>Concrete/Masonry: Wait until the concrete and/or masonry has cured at least 30 days before painting it.</p> <p>Aluminum, galvanized metal, and interior ferrous metal: Remove all traces of oxidation (rust), then clean with Metal Plus 467, metal conditioner.</p> <p>Wood: The surface must be sanded with a grit #80 or #100 sandpaper to smoothen the surface.</p>	<p>Drywall: Only 2 coats of Proline Eco 7035 can be applied directly onto the surface or the following primers can be used; Proline 6070 or Proline Eco 7065.</p> <p>Concrete block/rough brick: Only 2 coats of Proline Eco 7035 can be applied directly onto the surface or apply the Proline 6006 block filler to level the surface.</p> <p>New Concrete: Apply the Proline Eco 7035 directly onto the surface.</p> <p>New wood: Only 2 coats of Proline Eco 7035 can be applied directly onto the surface or use the Portico 270.</p> <p>Pine knots: Seal the pine knots with the Stop Plus 298.</p> <p>Red cedar and redwood: Apply one to two coats of Block Plus 296 alkyd based.</p> <p>Aluminum, galvanized metal, and interior ferrous metal: Apply a coat of Adhero Plus 290.</p> <p>Latex paint: No primer is required.</p> <p>Alkyd paint: Apply an undercoat of Adhero Plus 290*.</p> <p>Dark colours: Some dark colours may require the application of a dark tinted primer in order to improve opacity. Use Proline products 6070-2 and 6070-4 or Adhero Plus 290-2 and 290-4, available in more than 30 colours.</p> <p><i>If the surface to be primed is not mentioned, please contact an MF Paints distributor for further recommendations.</i></p> <p><i>*See limitations for Adhero Plus 290.</i></p>
APPLICATION	
<p>This product is ready to be used and does not require dilution. Mix well before use. Apply one coat or two if necessary. Allow a minimum drying time of 4 hours between each coat for pale colours and 8 hours for dark colours. In order to properly cover the surface, it is recommended to use a 15mm lint free roller and a quality nylon-polyester brush. Clean the brushes and rollers with lukewarm soapy water following their use.</p> <p>For spray application : Dilute with a maximum of 10% water.</p> <p>Pressure : 2000 to 2500 lb/in²*</p> <p>Nozzle : 0.017 – 0.021*</p> <p><i>*This data may vary depending on the brand of the equipment manufacturer</i></p>	
STORAGE	
Store the paint in a dry area and maintain temperature between 10°C and 30°C.	
WARRANTY	CAUTION
<p>This product will give full satisfaction if applied according to the manufacturer's instructions. Manufacturer's liability is limited to the replacement of the product and does not include manpower if found defective upon inspection.</p>	<ul style="list-style-type: none"> • Keep away from children's reach • Keep lid closed when not in use • Avoid freezing

" Contact your municipality to dispose of the container in an environmentally-friendly manner "