





Velvet
Acrylic Latex

## **INTERIOR**

# Technical Data Sheet

### **DESCRIPTION**

Proline Eco 7242 velvet finish is a Zero VOC acrylic latex paint for interior use. It can be applied directly onto porous surfaces without requiring a primer. It is easy to apply and dries quickly. It was developed to answer the needs of professional painters. Proline Eco 7242 can be used for commercial, institutional and residential projects.

### **USE**

Proline 7242 can be applied on porous surfaces. It is recommended for drywall, concrete, galvanized metal, aluminum, masonry, cement and wood. Easy cleaning and offering good resistance. it will retain its sheen and it has good colour retention.

# **ADVANTAGES**

- > Has exceptional hiding properties
- It is ideal for LEED projects or any other projects requiring Zero VOC paints.
- Formulated with low spattering, however during application, minimal protection is required for baseboards and flooring
- Provides a smooth surface with a minimum of texture.
- Can easily be sanded after 4 hours drying time without overloading the sanding paper.
- Can easily be cleaned with lukewarm soapy water.

## **LIMITATIONS**

- Avoid application in all temperatures under 10°C
- Do not use on flooring
- Not for exterior application
- Wait 30 days before proceeding with the first cleaning

# **TECHNICAL DATA**

Resin			Acrylic Latex	
Color			Natural White	
Cleaning			Water	
Flash point			N/A	
Inflammability			N/A	
Solids by weight			57 ±2	%
Solids by volume			42 ±2	%
VOC			Zero VOC	g/l
Gloss	60°		4,5-6,0	%
Sheen	85°		14-18	%
Standards/Certifications	LEED	Eligible for LEED® v4		

### **APPLICATION DATA**

At 25° Celsius								
Relative humidity at 50%								
May differ depending on the colour								
Spreading Rate May vary depending on the surface				37-46 m <sup>2</sup> (400-500sqft)	gallon			
Film Thickness	Wet			3,2-4,0	mils			
	Dry			1,34-1,68	mils			
Drying Time	Tack free			30	min			
	Recoat			4	hours			
	Cleaning	9		30	days			
	Cure			30	days			
Application	Brush			1				
	Roller			15	mm			
Max dillution 10%	Spray*	Nozzle:	0.017 – 0.021*	2000-2500	lb/po <sup>2</sup>			
*These data may vary depending on the equipment manufacturer								
Exterior application and	conditio	N/A						
Storage	Temperature			10-30	°C			
Tinted Bases	<b>Formats</b> 946ml 3,78L 18,9L			The Proline Eco will no longer be a 0 VOC paint when add colorants				
7242-3 Natural White		1	V	max. 3.5 oz of colorant/3,78 L				





Velvet Acrylic Latex

**INTERIOR** 

# Technical Data Sheet

## **SURFACE PREPARATION**

The surface must be dry and clean, without dust, oil, grease, rust and soap. On painted surfaces, it is recommended to clean with a degreaser (T.S.P.) in order to eliminate any contaminant that may harm the adhesion or the curing of the product. Thoroughly rinse the entire surface. The surfaces must be well sanded and dusted.

**Presence of mold:** Clean the affected area with a mixture of 1 part bleach to 3 parts water. Thoroughly rinse the entire surface.

**Flaking or peeling paint**: Using a scraper, remove the weakened and/or loose paint, then sand the edges of the surface to make it smooth.

A repair compound should be used to fill holes and uneven surfaces. Sand with a grade #100 sanding paper.

**New drywall**: To avoid creating an undesirable texture on the drywall, the joint compound must not be sanded excessively.

**Concrete / Masonry**: Wait until the concrete and/or masonry has cured at least 30 days before painting it.

**Aluminum, galvanized metal, and interior ferrous metal**: Remove all traces of oxidation (rust), then clean with Metal Plus 467, metal conditioner.

**Wood:** The surface must be sanded with a grade #80 or #100 sanding paper to improve adhesion.

### **RECOMMENDED PRIMER**

**Drywall**: Not needed or use primer Proline Eco 7070. **Concrete block / rough brick:** Not needed or apply the Proline 6006 block filler to level the surface

**New Concrete**: No primer is required.

**New wood:** Use the Adhero Plus 290 or Adhero Hybrid 297.

**Pine knots**: Seal the pine knots with the Stop Plus 298. **Red cedar and redwood**: Apply one to two coats of Block Plus 296 alkyd based.

**Aluminum, galvanized metal:** Apply a coat of Adhero Plus 290 or Metal Plus 4700 white.

Interior ferrous metal not rusted: Adhero Hybrid 297

Latex paint: No primer is required.

**Alkyd paint**: Apply an undercoat of Adhero Plus 290\* or Adhero Hybrid 297.

\*See limitations for Adhero Plus 290.

## **APPLICATION**

This product is ready to be used and does not require dilution. Mix well before use. Apply one coat or two if necessary. Allow a minimum drying time of 4 hours between each coat for pale colours and 8 hours for dark colours. In order to properly cover the surface, it is recommended to use a 15 mm lint free roller and a quality nylon-polyester brush. Clean the brushes and rollers with lukewarm soapy water following their use.

For spray application: May be diluted with a

maximum of 10% water. **Pressure**: 2000 to 2500 lb/in<sup>2\*</sup>

**Nozzle**: 0.017 – 0.021\*

\*This data may vary depending on the brand of the equipment manufacturer.

### **MAINTENANCE**

Allow 30 days drying time before proceeding with a first cleaning. Only use mild, non-abrasive cleaners and a soft cloth. Clean the surface using a light, circular motion.

### WARRANTY

This product will give full satisfaction if applied according to the manufacturer's instructions. Manufacturer's liability is limited to the replacement of the product and does not include manpower if found defective upon inspection.

# **CAUTION**

- Keep away from children's reach
- Keep lid closed when not in use
- Avoid freezing

Contact your municipality to dispose of the container in an environmentally-friendly manner.